


New A3AV2 Remote – (Green Led)

### How to copy a code to the A3A Remote.

#### To Button (1)

- 1 Press and hold button (1) (The led flashed quickly)
- 2 Keep button (1) pressed then press button (2) (The led flashes slower)
- 3 Keep button (1) pressed and release button (2) (The led becomes fixed)
- 4 Keep button (1) pressed and press the button you wish to copy on your old remote. Slowly pass this under the A3A. (The led will flash slowly again.) Please keep pressing for 2 second whilst this is happening.

Your remote is now copied release button (1), wait ten seconds and test.



#### To Button (2)

- Press and hold button (1) (The led flashed quickly)
- Keep button (1) pressed then press button (2) (The led flashes slower)
- Keep button (2) pressed and release button (1) (The led becomes fixed)
- Keep button (2) pressed and press the button you wish to copy on your old remote. Slowly pass this under the A3A. (The led will flash slowly again.) Please keep pressing for two seconds whilst this is happening.

Your remote is now copied release button (2), wait ten seconds and test.

#### How to generate a random code.

- Press and hold button (1) (The led flashed quickly)
- Keep button (1) pressed then press button (2) (The led flashes slower)
- Keep both buttons pressed for 15 seconds (The led will start to flash faster).
- Whilst still holding in buttons (1) & (2), Release button (1) wait 2 seconds and release button (2).
- You have now generated a random code in both buttons.

